



VIDEO TUTORIAL

### Important!

This replacement procedure can be used for:

FIAT PANDA (169\_) 1.2 (169.AXB11, 169.AXB1A), FIAT PANDA (169\_) 1.2 LPG (169.AXB1A), FIAT PANDA (169\_) 1.2 Natural Power (169.AXB1A), FIAT PANDA Van (169\_) 1.2, FIAT PANDA Van (169\_) 1.2 LPG, FIAT PANDA Van (169\_) 1.2 Natural Power, FIAT PUNTO (188\_) 1.2 60 (188.030, .050, .130, .150, .230, .250), FIAT PUNTO (188\_) 1.2 Bifuel, FIAT PUNTO (188\_) 1.2 Natural Power, FIAT PUNTO Van (188\_) 1.2 60

---

The steps may slightly vary depending on the car design.

## REPLACEMENT: BRAKE PADS – FIAT PUNTO 188. PROFESSIONALS RECOMMEND:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Wheel impact socket #19
- Brake caliper wind back tool
- Torque wrench
- Flat Screwdriver
- Crow bar
- Wheel chock

## Replacement: brake pads – Fiat Punto 188. AUTODOC experts recommend:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- Please note: all work on the car – Fiat Punto 188 – should be done with the engine switched off.

### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1



Open the bonnet. Unscrew the brake fluid reservoir cap.

2



Secure the wheels with chocks.

3



Loosen the wheel mounting bolts. Use wheel impact socket #19.

4



Raise the front of the car and secure on supports.

5



Unscrew the wheel bolts.

### AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. Fiat Punto 188




6




Remove the wheel.

7



Spread the brake pads. Use a crowbar.

8



Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.

9

Remove the brake caliper cotter pin. Use a flat screwdriver.

10



Remove the brake caliper fastener. Use a flat screwdriver.

11



Remove the brake caliper.

## Replacement: brake pads – Fiat Punto 188. Tip from AUTODOC experts:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.



12



Remove the brake pads.

### Replacement: brake pads – Fiat Punto 188. AUTODOC experts recommend:

- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

13



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.

## AUTODOC recommends:

- Replacement: brake discs – Fiat Punto 188. After applying the spray, wait a few minutes.

14



Treat the brake caliper piston. Use a brake cleaner.

Replacement: brake pads – Fiat Punto 188. After applying the spray, wait a few minutes.

- After applying the spray, wait a few minutes.

15



Press in the brake caliper piston. Use brake caliper wind back tool.

16



Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.

**Replacement: brake pads – Fiat Punto 188. AUTODOC experts recommend:**

- Make sure the disc surface is clean before installing the pads.

17



Install new brake pads.

Replacement: brake pads – Fiat Punto 188. AUTODOC recommends:

- Make sure the pads are installed with linings facing the disc.


18



Install the brake caliper and fix it.




19



Install the brake caliper fastener.

20



Install the brake caliper cotter pin.



21



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

22



Clean the brake disc surface. Use a brake cleaner.

## AUTODOC recommends:

- Replacement: brake pads – Fiat Punto 188. After applying the spray, wait a few minutes.

23



Install the wheel.

### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. Fiat Punto 188

24



Screw in the wheel bolts. Use wheel impact socket #19.

**25**


Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.

**26**


Remove the jacks and chocks.

## Replacement: brake pads – Fiat Punto 188. Professionals recommend:

- Check the brake fluid level in the expansion tank and refill if necessary.

27




Tighten the brake fluid reservoir cap.

### Replacement: brake pads – Fiat Punto 188. Tip from AUTODOC:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.



28



Close the hood.

### Replacement: brake pads – Fiat Punto 188. AUTODOC recommends:

- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unnecessary and sharp braking to a stop.



**DID YOU FIND THESE INSTRUCTIONS  
HELPFUL?**

**YES**

**NO**



**BECOME A MEMBER OF AUTODOC CLUB!**

## AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



**AUTODOC APP**

**Download**

 **Google play**

 **App Store**

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



## BUY SPARE PARTS FOR FIAT



## BRAKE PADS: A WIDE SELECTION



CHOOSE CAR PARTS FOR FIAT PUNTO 188



BRAKE PADS FOR FIAT: BUY NOW



## BRAKE PADS FOR FIAT PUNTO 188: THE BEST DEALS & OFFERS



### Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.